



**Choose 2 Rent**

Phone 1 (800) 622-6484

Fax 1 (866) 937-8254

**info@choose2rent.com**

**www.choose2rent.com**

## Connect your Equipment

1. Turn on the T-Mobile 4G LTE ZTE HotSpot




2. Check if your Hotspot connects to the T-Mobile 4G LTE ZTE HotSpot Network




<b>2G</b>	Indicates that your Mobile HotSpot is on T-Mobile's 2G network.
<b>3G</b>	Indicates that your Mobile HotSpot is on T-Mobile's 3G network.
<b>4G</b>	Indicates that your Mobile HotSpot is on T-Mobile's 4G network.
<b>4G LTE</b>	Indicates that your Mobile HotSpot is on T-Mobile's 4G LTE network.

3. Connect the power cord of the Brother QL-710W Printer



4. Turn on the Brother Printer




5. The Wi-Fi connection between the Brother Printer and the Hotspot should be established automatically. The following chart displays a proper connection:



Use the **Right key** and select the third tab (3) and press **OK** to select



	Wi-Fi status and number of the connected users.
	Shows and checks the clients connected to your device.




The Wi-Fi lamp is **SOLID GREEN** (no flashing)


6. Connect the Brother Printer and the Hotspot manually over Wi-Fi (*this applies only if step 5 shows no proper Wi-Fi connection*)



Use the **Right key** and select the fourth tab (4) and press **OK** to select



	Set the WPS function.
--	-----------------------




Press the Wi-Fi button on the printer **for 5 seconds** until it starts flashing



7. Connect your iPads to the T-Mobile 4G LTE ZTE HotSpot Network  
**(Rental iPads are automatically connected)**

- On the Hotspot, you will find a label with the network ID and its Password
- Search for the Wi-Fi network on your iPad and connect using the password printed on the label

8. Charging the T-Mobile 4G LTE ZTE HotSpot



1. Connect the USB cable to the charging head
2. Locate the Charging port
3. Insert the USB cable into the device's Charger/Accessory jack
4. Plug the charging head into a standard AC power outlet

*Please note: The unit cannot be plugged into the charging when being used. It will disable the WIFI and put the device into a "Charge Mode".*

Please call our support team if you need assistance  
setting up your rental devices  
1(800) 622-6484