RENTAL EQUIPMENT SETUP GUIDE

Socket Mobile D750

Shipment Content:
1 x Scanner
1 x Charging Cable
1 x Charging Plug

Quick Setup:

1. **Turn ON the scanner:** Press and hold down the small power button until the battery and LED lights are lit solid (pre-paired) or blinking (HID pairing mode) and the scanner beeps twice. Follow the same steps to **Power OFF** the scanner.

Pair the Scanner to the iOS device:

1. On your iOS device go to Settings.
2. Enable Bluetooth on the iOS device by going to selecting Bluetooth > toggle button to ON (green). The unit will search for Bluetooth devices.
3. In the list of the found devices, select Socket CHS [XXXXXX]. *This will be the unit's S/N that can be found on a sticker under the scanner head*.
4. Optional: When connecting more than one unit, connect one at a time then turn them off to avoid overlapping.

HID MODE keyboard Pop-up Enable

The scanner emulates the keyboard in HID mode. Scanned barcode data will be input into the text field.

HID-keyboard (default)

1. Activate HID by scanning this QR code.
2. Once the device is discoverable the Bluetooth light will blink on the scanner.
3. Find and pair the scanner to iOS device following steps in **Pair the Scanner to the iOS device** section.
4. Once paired open your application and place the cursor where you want to enter the data

iOS MODE – Scanner-Enabled App

Use this mode with an iOS app designed for Socket Mobile barcode readers.

iOS Mode

1. Activate iOS mode by scanning this QR code.
2. Find and pair the scanner to iOS device following steps in **Pair the Scanner to the iOS device** section.
3. Launch your reader-enabled application. The reader will beep once indicating that it is connected to the appropriate application.

1. **Scanning Barcodes:** After connecting to your device, open an application. Put the cursor where you want to enter data. Hold the scanner about 4 inches from the barcode and press and hold the trigger button. Keep your hand steady and make sure the red beam covers the entire barcode width. *By default, the scanner will beep and vibrate, and the LED will flash green. This is to confirm that data was decoded and sent to the host device.*

Setup Video Guide:
Scan this QR code with your phone camera for video.

Contact our Support Team:
www.choose2rent.com/help
+1 (800) 622-6484 Ext. 3 (USA)

Socket Mobile D750

BEEP and Vibration Settings.

Disable Beep only

Enable Vibration and Beep (default)

Disable Vibration only

Disable Vibration and Beep

Troubleshooting:

What if…

… the scanner does not pair to your device?	The scanner may be connected to another device. Unpair the scanner using the following steps: 1-Power on the scanner. 2-Press and hold the TRIGGER and POWER buttons. 3- Once you hear 3 beeps, release both buttons. 4- The scanner will unpair and power off.
… I need to reset the scanner?	Factory Reset. Revert all settings to factory defaults. The scanner powers off after scanning this barcode.
… I am unable to scan a QR code on a mobile device?	Be sure the brightness is set to highest on the mobile device. Be sure to enlarge the QR code to a reasonable size.
… I am unable to scan a QR code?	Be sure to place the QR code 4-6 inches away from the scanner and slowly back away the QR code until a beep sound is made. Do not wave! Move in and out.

Setup Video Guide:
Scan this QR code with your phone camera for video.

Contact our Support Team:
www.choose2rent.com/help
+1 (800) 622-6484 Ext. 3 (USA)